

# STEPFOLD 500 PODIUM



## STEPFOLD 500 PODIUM

This unit is ideal for all trades to help get to those just out of reach places without difficulty, ideal for installation, maintenance or snagging at the end of the job.

Suitable for use on flat ground, providing platform levels of 0.25m and 0.50m

### Unique Features:

- 2 working heights, 2.25m and 2.50m
- Easy to assemble in minutes
- Platform area ideal size for one person and tools.
- Folds flat to fit in a van for easy transport and storage.
- Open or folded the unit easily passes through a standard door,
- Non slip platform board.
- Gated access to allow ease of entry and exiting to and from the unit
- Stabilizers included with every unit



# MKTOWER SERVICES LTD

HIRE - SALES - REPAIRS - TRAINING

**Tel: 0844 884 5191 | [www.mktowerservices.com](http://www.mktowerservices.com)**

Address: Unit 6A Pineham Farm - Haversham - Milton Keynes- MK19 7DP | [Ben@MKTower.com](mailto:Ben@MKTower.com)

# STEPFOLD 500 PODIUM

## STEPFOLD 500 PODIUMS

### Assembly Instructions

- Ensure all parts are present and are not damaged before assembling.
- This unit is not designed for heavy loads.
- One person unit only.
- Please ensure that any weight is dispersed as evenly as possible

#### COMPRISING OF...

4 x 5" Castor C/w Adaptor  
(OR 2 x Castors & 2 x Anti Surf Base Plates)  
1 x Podium 500 Base Unit  
1 x Podium 500 Platform  
1 x Podium 500 Step Brace

1. Open Base out and lock folding section in desired location.
2. Place platform on required rung and lock castors.
3. Fit the Step Brace to the verticals above the platform for 0.25m or below the platform for 0.50m on the side away from the gate locating above the corresponding rung.
4. Enter unit and close the gate behind you before commencing work.
5. Dismantling is reverse of assembly.

**REMEMBER YOUR SAFETY  
DEPENDS ON THE SAFE  
ASSEMBLY AND USE OF THIS  
EQUIPMENT.  
ALWAYS CLOSE THE GATE.**



#### General Safety Rules:

1. Do not use if the product is damaged or has parts missing
2. Do not use on unstable ground such as loose bricks, boxes or blocks
3. Always check the unit is level before use.
4. Remove all personnel and materials before moving the unit.
5. Do not gain extra height by using boxes, ladders etc. on the platform.
6. If there is an overhead hazard use head protection.
7. Do not over load the unit
8. Do not overreach out of the unit
9. Engage all stabilizers in their correct position before use on staircases.
10. Never climb the outside of the unit.
11. Never use the guardrails to gain extra height.

**Maximum safe working load  
150Kg**

This unit can also be converted into a Stairpod 500 Podium, Please contact us for more information with how to proceed.



**Tel: 0844 884 5191 | [www.mktowerservices.com](http://www.mktowerservices.com)**

**Address: Unit 6A Pineham Farm – Haversham - Milton Keynes- MK19 7DP | Tel: [info@mktowerservices.com](mailto:info@mktowerservices.com)**